

CAUTION
 READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION.
 TURN MAIN POWER OFF BEFORE BEGINNING.

Ground	Utilizes A,B1, B2, B3, D, E,F
---------------	-------------------------------

- 1 Please make sure main power is off to avoid electrocution.
- 2 Secure the anchor bolts **A** (provided) to the concrete footing while it is being casted.
- 3 Attach bollard base **B1** to the concrete footing by aligning to bolts **A**.
- 4 Secure the bollard base **B** to the concrete footing using washer **D** and nut **E**.
- 5 Connect Livewire in **B4** (white) to main power Live (white) using wire connector **F** (not provided).
- 6 Connect ground wire in **B5** (green) to main power ground (green) using wire connector **F** (not provided).
- 7 Connect neutral wire in **B6** (black) to main power neutral (black) using wire connector **F** (not provided).
- 8 Connect bollard body **B2** to bollard base **B1** by screwing in screws **B3** firmly.

