

**CAUTION**  
 READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION.  
 TURN MAIN POWER OFF BEFORE BEGINNING.

**Ground** Utilizes A,B1-76,D,E,F

- 1 Make sure main power is off to avoid electrocution
- 2 Secure the anchor bolts **A** (provided) to the concrete footing while it is being casted.
- 3 Attach bollard base **B1** to the concrete footing by aligning to bolts **A**.
- 4 Attach triangle support **B2** to bollard base **B1** by aligning to bolts **A**.
- 5 Secure the bollard base **B1** to the concrete footing using washer **D** and nut **E**.
- 6 Connect Live wire in **B3** (white) to main power Live (white) using wire connector **F** (not provided).
- 7 Connect ground wire in **B4** (green) to main power ground (green) using wire connector **F** (not provided).
- 8 Connect neutral wire in **B5** (black) to main power neutral (black) using wire connector **F** (not provided).
- 9 Connect bollard body **B6** to bollard base **B1** by screwing in screws **B7** firmly.

