Installation Instructions

Architecture LED Linear-Direct

Installation guide valid for the following models: ILA-2D ILA-4D ILA-6D ILA-8D



WARNING

RISK OF FIRE OR ELECTRIC SHOCK

The ILA Series must be installed by a qualified electrician in accordance with applicable federal, state, and local laws and codes. Installation requires knowledge of luminaire electrical systems and installer should be familiar with the operation of this product. If not qualified, do not attempt installation; contact a qualified electrician. Manufacturer assumes no responsibility for the improper installation of this luminaire. When installing the fixture, drilling may damage luminaire wiring and electrical parts. Check for wiring and components in enclosure before drilling.

WARNING

To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects. When installing this kit, drilling may damage luminaire wiring and electrical parts. Check for wiring and components in enclosure before drilling.

CAUTION

RISK OF PERSONAL INJURY

- Wear gloves or proper handling protection to prevent cuts or abrasions when handling and maintaining this product. This equipment may have sharp edges. To reduce the risk of death, personal injury or property damage from fire, electric shock, falling parts, cuts/abrasions, and other hazards read all warning and instructions included with and on the fixture box and all fixture labels.

- Avoid direct eye exposure to the light source while it is on.

WARNING

RISK OF PERSONAL INJURY, FIRE OR ELECTRIC SHOCK

-Turn OFF power before installation.

-Do not handle energized fixture when hands are wet, when standing on wet or damp surfaces, or in water

NOTICE


- Do not install any part of the luminaire less than 5 feet above the floor or closer than 5 inches from any window treatments, i.e., curtains, blinds or any similar combustible type materials.

-Check to make sure that all fixture connections have been properly made and the fixture is grounded to avoid potential electrical shocks.

-Use only UL approved wire input/output connections. Minimum size 18 AWG if there are any continuous runs. -If the fixtures are connected in a continuous run, do not exceed allowable number of fixtures in series/power in continuous runs.


Contact manufacturer with any questions or concerns regarding installation of this luminaire.










Canopy Suspension Installation






Surface Mount Installation










1.Drill Hole on the ceiling based on the Length of the fixture, fix the plastic anchor in the hole .


< <u> </u>			B		С	
1.18"						
	No.	Size	A(in)	B(in)	C(in)	
	1	2FT	18.898	1	/	
	2	4FT	42.520	/	/	
	3	6FT	25.984	14.173	25.984	
	4	8FT	37.795	14.173	37.795	ļ






4. Wiring the fixture with the supply power, clear up the wires and safety cables, clip the fixture into the slot of the surface mount plate on two sides.












Wall Mount Installation










1. Drill Hole on the wall based on the Length of the Fixture, Fix the plastic anchor in the hole and fix the Wall Mount Bracket on the Wall.

2. Push the L support bracket into the wall mount bracket as followed.
















T-BAR Recessed Installation




















Dry Ceiling Wall Recessed Installation
















Linkable Installation

Note:Only available for Linkable Products.

