

APPLICATION:

Application for workshops, factories, office, shopping malls, large supermarkets, exhibition halls, warehouses, homes, hotels, schools and more.

FEATURES:

- External driver – male and female connection
- Easy to fix by magnet and screws
- Eco-friendly without mercury

Magnet Troffer Retrofit Kit 2X4 36W Spec

LOD-MTRT-4FT36WX2 4000K

LOD-MTRT-4FT36WX2 5000K



SPECIFICATIONS:

SPECIFICATION	Details	
Model	LOD-MTRT-4FT36WX2 4000K	LOD-MTRT-4FT36WX2 5000K
Input Wattage (W)	36W	36W
Lumens Delivered (LM)	4,625.48LM	4,859.36LM
Efficacy (LM/W)	124.7LM/W	131LM/W
CRI	83.5	82.4
Lifespan	50,000 hours	50,000 hours
Color Temperature	4,000K	5,000K
Wattage Equivalent	Replaces 2 x 4 panel	Replaces 2 x 4 panel
Dimmable	Yes	Yes
Input Voltage	AC100-277V	AC100-277V
Power Factor	0.8889	0.99
Housing	Aluminum	Aluminum
Lens	Frosted	Frosted
Mounting	Magnetic Screw	Magnetic Screw
Size	43.31" x 21.26" x 0.69"	43.31" x 21.26" x 0.69"
THD	13.3%	13.3%
Certification	DLC, ETL, FCC, CE RoHS, TUV, ISO9001	DLC, ETL, FCC, CE RoHS, TUV, ISO9001
Operating Temperature	-20°C to 50°C (-4°F to 122°F)	-20°C to 50°C (-4°F to 122°F)
Environment	Indoor	Indoor
Warranty	5 years	5 years






Step 1:
Cut off the power of the troffer retrofit kit before any operation. Pull the movable bolt at the edge of the troffer retrofit kit and open the cover.



Step 2:
Take out the fluorescent tubes one by one.



Step 3:
Open the top cover of wiring box.




Step 4:
Dismantle the ballast and circuit of the fluorescent tubes.



Step 5:
A. Take out the LED Magnet Tubes from the package box. B. Stick the LED Tubes onto the troffer. Adjust its position to make sure they are placed horizontally in proper position.




Step 6:
Take out the LED driver and screws we provide; fix the drivers onto the position of the previous ballast.



Step 7:
Connection mode of LED Driver's Input Wire (See Fig. 7):
White: Live Wire
Black: Null Wire
Yellow/Green: Ground Wire



Step 8:
Connect the Connection Wire to the OUTPUT terminal of the LED driver.



Step 9:
Connect the Connection Wire to the LED Tubes through 2P socket one by one.



Step 10:
Finish all connections between LED driver and LED strips.



Step 11:
Install the top cover of the wiring box to cover the LED driver.



Step 12:
Pull the movable bolt at the edge of the troffer retrofit kit and close the cover slightly.



Step 13:
Recover the power supply and have a test. Replacement of LED Magnet Tubes is completed.



- Warning**
1. Please cut off the power before any installation or maintenance work.
 2. Please strictly follow the operation rules and use right tools in the installation.
 3. The light fixture shall be installed, connected and tested by licensed electricians only.